



## PLEASE NOTE

### 21 Before fitting leaf springs



Remove the cap screws from the bottom of the leaf mounts on both front and rear axles



Replace with M3 x 4mm screws supplied